

## Installation Instructions for the Drawer Safe

Installation of the safe requires a suitable drawer that has capacity to hold approximately 50 lbs (19 kg). The drawer bottom will support the weight and should be sturdy.

The standard Drawer Safe has four holes in the bottom that can be attached to the drawer bottom with wood screws and washers or bolts and nuts.



Place the safe into the drawer and pencil-mark the location of the four holes. Using a 5/16<sup>th</sup>" (8mm) diameter drill bit to drill the four holes through the bottom of the drawer. Place the safe into the drawer and insert the four bolts down and through the drawer bottom, attach the washer and nut underneath.

The safe might also be attached to the drawer bottom using wood screws with washers providing the drawer bottom is at least 1/2" (12mm) thick.

### Security Cable

There is also a hole on the back of each safe to attach a security cable that would then be fastened to the cabinet or the wall itself. This cable is optional and sold separately.



The cable is necessary to secure the safe from being lifted out of the drawer or the whole drawer being removed with the safe.

## Remove the battery activation tab and corner protectors on the door



## Insert the Override Lock

If the safe has the key/lock override feature, it is necessary to install the lock core before the safe is used. Use the key with the round head to insert or remove the lock core.



## Programming the Safe

It is necessary to program each safe before the safe is used. Your user manual will detail the programming steps.

