

# **52 SERIES**

### **MODELS 52 & T52**

## SUPER MASTER OPERATIONS

The following instructions cover **Model 52 & T52 Super Master Operations**. The Super Master Combination is a six-digit combination used to reset the lock to the factory default combination (**50 25 50**) in the event the user combination(s) are lost.

#### SET SUPER MASTER COMBINATION

WARNING: <u>Super Master Control will be permanently lost if you do not change the default Super Master Combination prior to changing any User combinations</u>. Caution: Once the Super Master Combination is set, it can never be changed. Record the combination and store it in a secure place.

- 1. If operating a self-powered lock, power the lock by turning the dial back U and forth U in both directions until simultaneous green ☐ and red ☐ flashes display with a beep ◆ ...
- 2. Press (ENTER). Press (1).

  One green flash (a)- displays with a beep (1).
- 3. Enter the factory default Super Master Combination of
  1 2 0 9 4 3.
  One green flash -6 displays with a beep <1.</li>
- Enter the new six-digit Super Master Combination.
   One green flash o displays with a beep <</li>
- 5. Enter the new Super Master combination again for verification.

  Simultaneous green - and red flashes indicate operation completed successfully.

#### RESET LOCK USING SUPER MASTER COMBINATION

- 1. If operating a self-powered lock, power the lock by turning the dial back  $\circlearrowleft$  and forth  $\circlearrowright$  in both directions until simultaneous green  $\multimap$  and red  $\multimap$  flashes display with a beep  $\blacktriangleleft$ .
- 3. Enter the Super Master combination.

  Simultaneous green and red flashes indicate operation completed successfully.

Note: The lock is now set to the factory default: Single Mode with an opening combination of "50 25 50".

### **DETECT IF SUPER MASTER COMBINATION IS ACTIVE**

- 1. If operating a self-powered lock, power the lock by turning the dial back of and forth of in both directions until simultaneous green in and red in flashes display with a beep in .
- 2. Press (ENTER). Press (9)

If the Super Master User combination has not been disabled (i.e., no User combination has been changed) and has not been activated, two red flashes - 6-display.

If the Super Master combination has been permanently disabled, a green flash - o-displays.



Kaba® Mas Corporation 749 W. Short Street, Lexington, KY 40508 USA Phone: (859) 253-4744 FAX: (859) 255-2655 Technical Support: (800) 950-4744 www.kaba-mas.com