## **ECONOMY PUSHBUTTON**





## **Instructions**

- 1. Solder the leads to the switch according to the diagram below.
- 2. Ensure that all connections are properly attached to the terminals according to the mode of electrical device.
- 3. Connect leads to the electric locking device and check for proper operation, then fasten the face/mounting plate to a utility box (supplied by others).

## **Switch Terminals**

- a & b Lamp (not provided)
- 3 & 4 normally open
- 1 & 2 normally closed





Description	Switch Mode	Switch Configuration	Switch Rating	Standard Finish
980-MO Pushbutton	Momentary Action	2-SPST	5A @250V	32D

NOTE: Specifications are subject to change without notice.