

In der Montage- und Bedienungsanleitung des CS80 MAGNEO (WN 058253 45532) ist das Kapitel "DIP-Schalter-Einstellungen" auf Seite 32 durch das folgende zu ersetzen.

Der 8-polige DIP-Schalter wird durch einen 10-poligen DIP-Schalter ersetzt.

Die Funktionen von DIP 1 bis DIP 8 bleiben identisch.




Abb. 1 Bedien- und Anzeigeelemente

Übersicht der DIP-Schalter-Einstellungen

DIP 10	ON	ohne Funktion
	OFF	ohne Funktion
DIP 9	ON	ohne Funktion
	OFF	ohne Funktion
DIP 8	ON	Verriegelung
	OFF	keine Verriegelung
DIP 7	ON	Erhöhter Endschub
	OFF	Sanfter Endschub
DIP 6	ON	Betriebsart DAUERAUF aktiv
	OFF	Betriebsart AUTOMATIK aktiv
DIP 5	ON	Taster außen aktiv
	OFF	Bewegungsmelder außen aktiv
DIP 4	ON	Taster innen aktiv
	OFF	Bewegungsmelder innen aktiv
DIP 3	ON	Test high aktiv
	OFF	Test low aktiv
DIP 2	ON	Test Sensor Nebenschließkante aktiv
	OFF	Test Sensor Nebenschließkante inaktiv
DIP 1	ON	Test Sensor Hauptschließkante aktiv
	OFF	Test Sensor Hauptschließkante inaktiv

CS80 MAGNEO

Ergänzung zur Montageanleitung
Supplement to the mounting instructions

WN 059458 45532 – 2018-07

DE | EN

In the mounting and operating instructions of the CS80 MAGNEO (WN 058253 45532), replace the chapter „DIP switch settings“ on page 32 with the following.

The 8-pin DIP switch is replaced by a 10-pin DIP switch.

The functions of DIP 1 to DIP 8 remain identical.




Abb. 1 Operating and display elements

Overview DIP switch settings

DIP 10	ON	without Function
	OFF	without Function
DIP 9	ON	without Function
	OFF	without Function
DIP 8	ON	Locking function
	OFF	No locking function
DIP 7	ON	Enhanced closing force
	OFF	Reduced closing force
DIP 6	ON	Permanent Open Function activated
	OFF	Automatic Function activated
DIP 5	ON	External pushbutton activated
	OFF	External motion detector activated
DIP 4	ON	Internal pushbutton activated
	OFF	Internal motion detector activated
DIP 3	ON	Test high aktiv
	OFF	Test low aktiv
DIP 2	ON	Sensor test for secondary closing edge activated
	OFF	Sensor test for secondary closing edge deactivated
DIP 1	ON	Sensor test for main closing edge activated
	OFF	Sensor test for main closing edge deactivated