
dormakaba 🞽

Installation Instructions

Center Hung Bottom Arm 7422 (Aluminum)

1.1 Install bottom arm (7422)

Fig. 1



- 1.1.1 Prepare door according to template.
- 1.1.2 Install 4 lateral support screws in arm securely.
- 1.1.3 Fasten arm to door with 4 pan head machine screws.
- 1.1.4 Secure end of arm with flat head machine screw.1.1.5 Turn the 4 lateral support screws counter
 - clockwise until head of screws firmly contact door.

1.2 Install door

Fig. 2

